



SWM G01

????: **1 438 220 ???.**

?????????: **1.5 ?. 7AMT (139 ?.) FWD**

???????? ?????: **Prime**

???????? ?????:

????: **4610**

????: **1855**

????: **1740**

?????, ??: **2750**

?????, ??: **1575**

????, ??: **1575**

????, ??: **52**

???? (??, ???): ?????

???? (??, ???): ?????

????: ?????, ?????

????: ?????, ?????

????, ??: **1.5**

????, ??: **1499**

????: ?????

????: ?????

????: **7**

????: ?????

????, ??: **139**

????, ?/100 ??: **7.5**

????, ?/??: **180**

????, ??: **1625**

????, ??: **1925**

????, ??: **212 ??? 4000**

???? ????:

????

* ????? (????) ISOFIX

* ?????

* ?????

- * ?????????? ??????
- * ?????? ???????? ? ??????
- * ??????? ?????????????? (ESP)
- * ??????? ?????????????? ????????
- * ??????? ?????????????? ????????
- * ??????? ?????????????? ????????
- * ?????????????????????? ???????
- * ??????????? ??????? ??????? ???????
- * ?????????????????????? ??????? (ASR)
- * ??????? ??????? ??? ??????? ? ???? (HSA)
- * ??????? ??????? ??? ??????????? (BAS, EBD)

?????????

- * ?????????????? ????
- * ??????? ??????? ????
- * ?????????????????? ?????????? ???
- * ?????????? ?? ??????

????????

- * ?????????????????????? ??????? (ABS)
- * ??????????? ???????
- * ??????? 12V
- * ??????????? ??????? ????????? ?? ??????
- * ??????-?????????
- * ?????????? ?????????? ?????????
- * ?????????? ?????????? ???????
- * ?????????? ??????? ?????????
- * ?????????????????? ???????
- * ???????-????????? 1-???????
- * ?????????????????? ??????? ???????
- * ?????????????????????????? ??????? ???????
- * ?????????????????????????????? ?????????
- * ?????????????????????????????? ???????
- * ??????? ??????? ??????? ?????????? Driving Mode Selection
- * ??????????????? ??? ? ? ??????
- * ??????? ??????? ??? ??????

????????

- * ??????????????? ???? (????????? ???????)
- * ?????????? ??????????
- * ??????? ??????????????
- * ?????????????????? ??????? ???????

?????

- * ?????????????? ??????? ? ??-???????

?????

- * ??????? ?????????? ? ???????
- * ??????? ??????????? ??????? ??????? Auto Light Assistant
- * ?????????? ???????-?????????