



? . ??????, ?????????? ???? 321, ??????? 1

+7(345)258-30-75?

## Soueast DX5

?????: **1 550 000 ???.**

???????????: **1.5 ? . 5???? (120 ?.?) FWD**

????????? ????????????: **Elite**

????????????? ??????????????:

?????: **4406**

?????: **1840**

?????: **1654**

????????? ???, ?: **2615**

????????? ???, ?: **1585**

????? ???, ?: **1586**

????? ????????, ?: **45**

????????? ?????? (???, ??????): **????????? ??????????????**

????? ?????? (???, ??????): **?????????**

????? ??????: **?????????????, ??????????**

????? ??????: **?????????????, ??????????**

????? ????????, ?: **1.5**

????? ?????? ????????, ?: **1499**

?? ??????: **???????**

????? ??????: **?????????????**

????? ??????: **5**

?? ??????: **?????????**

???????, ?: **120**

????? ?????? ? ??????, ?: **8.6**

????? ?????? ?? ??????, ?: **5.7**

????????? ?????? ??????, ?: **6.9**

????????? ??????, ?: **200**

????????? ??????, ?: **1300**

????. ??????? ??????, ?: **143 ??? 4000**

????? ??????????:

?????????????

\* ?????? ?????????? (ESP)

\* ?????? ?????? ?????? (????? ???) ISOFIX

\* ??????? ?????? ??? ?????????? (BAS, EBD)

\* ??????? ?????? ??? ?????? ? ??? (HSA)

\* ?????????????????? ?????? (ASR)

\* ?????????? ?????? ?????? ??????

\* ??????? ?????????????? ??????????

\* ??????? ?????????????? ??????????

\* ??????? ?????? ??? ??????

\* ??????? ?????? ???? ?????

\* ????????????

**???????????**

\* ??????????????? ????

\* ??????? ??????? ????

**???????**

\* ?????????? ????

\* ?????? (????????? ????)

\* ?????????????????? ?????? (ABS)

\* ?????????????????????????? ????????

\* ?????????????????????????? ????????

**???????????**

\* ?????????????? (????????? ????)

**?????**

\* ??????? ?????????????? ????????????